



reAL Krome light

User Instruction

1. Base Color Application

Paint your favorable base color glossy: Black or Grey (either urethane or lacquer can be used)
Make sure to paint glossy.

*Please avoid to use base color that's extremely low film builds or non-glossy one.

2. Dry the base color

Depending on what type of paint is used or temperature, dry at least 1 hour.
Make sure to allow ample time to dry and wait until the base color is completely harden.

3. Apply reAL krome light

Use reAL krome light straight (without mixing) and make sure to spray lightly at each coat.
Spray lightly 3-5 times or until it becomes your desired tone.

* In case of splatter, get rid of it with soft cloth. Splatter causes the paint to less shine.

4. Dry reAL krome light

Dry reAL krome light more than 24 hrs. at room temperature of 20°C or above.

5. Clear coat

We recommend to use Krome 1K topcoat clear micro bottle 15 ml (KRM-1KC)

Recommended Topcoat clear: Hyper Krome Ag 1K topcoat clear.

(<https://www.showup.jp/othersE.html>)

Make sure to mist coat 2 times and wait until completely dries and move on to wet coat.

*If other brand's topcoat clear is used, color tone may change due to solvent absorption in the base coat.

Make sure to try it first, before use it on the object you are painting.



Signal Inc., SHOW UP Division, 2-6-8 Aoshinke Mino Si Osaka, Japan 562-0024

<https://www.showup.jp/indexEg.html>