



## Glow Color Micro Bottle Instruction Manual

Thank you very much for purchasing the Glow Color Micro Bottle. Please read the manual carefully and enjoy using Glow Color.

### Painting Manual

Glow Color is a phosphorescent paint that can be used simply by thinning with diluent. After lights are turned off, the glow can last for approximately 2 hours.

#### -Surface Preparation

Lightly sand the painting surface with commercially available sandpaper or apply primer treatment.

#### -Base Color

Apply white as the base color.

(We recommend "SHOW UP Base Color Micro Bottle – Air White EBC07MCB".)

#### -Glow Color Application

After applying the base color, apply Glow Color.

(We recommend using an airbrush with a 0.5 mm nozzle.)

Thin the Glow Color with 100%–150% Micro Bottle Thinner before use.

Apply 2 to 5 coats, allowing for proper setting time between each coat.

If necessary, finish with a topcoat clear after applying Glow Color.



-After painting, clean your airbrush thoroughly using SHOW UP Cleaning Thinner (CTHI) or equivalent.

### Precautions for Use

If you feel unwell during or after use, seek medical attention immediately.

In case of accidental contact with eyes or mouth, rinse thoroughly with water and consult a physician without delay.

Wear a mask, protective gloves, and protective clothing during use.

Avoid prolonged inhalation of vapors.

Do not leave the product near open flames or in high-temperature areas, as it may ignite.

For other manuals on the Hobby Color Series, please refer to our website.



SIGNAL Inc., SHOW UP Division  
2-6-8 Aoshinke, Mino-shi, Osaka 562-0024 JAPAN  
Tel. +81-72-727-7123 Email: info@showup.jp

